

TimberGlow

Wood Burning Sauna Heater Installation Instructions

(Chimney Out the Side/Back)



Requirements:

2 People (recommended)

Cordless Drill
Phillips & Robertson Drill Bits
2" hole Saw
Jig Saw
Carpenters Level

Tape Measure
Step Ladder
11mm Socket
13mm Socket

TimberGlow Wood Burning Sauna Heater Installation Instructions

**Congratulations on the purchase of your
Leisurecraft Timberglow wood burning sauna heater.**

Please read this entire manual before proceeding with installation.

Thank you for choosing Leisurecraft!

It is highly recommended to view the assembly video prior to starting assembly!

[Click here to View the assembly process or scan the QR code.](#)



Manufactured by:



tel: 888-923-9813 | info@leisurecraft.com | [web: www.leisurecraft.com](http://www.leisurecraft.com)

TimberGlow

Wood Burning Sauna Heater

Installation Instructions



Before Starting the assembly of your TimberGlow wood heater, remove the protective film from the heater shield and floor plate.



Place the heat shield on the floor in the sauna where the stove will be.



Bring the heater in and place it on top of the floor shield.



Place the shorter chimney connector piece onto the flange off the heater.

Manufactured by:



TimberGlow

Wood Burning Sauna Heater

Installation Instructions



Connect the chimney elbow to the first chimney connector piece.



Connect the last chimney connector to the other end of the chimney.



Place the wall heat shield ensuring it is centered.

Once in correct position, trace out the opening of the heat shield and then put the shield aside for the time being.



Cut out the opening with a jig saw.

Manufactured by:



TimberGlow

Wood Burning Sauna Heater

Installation Instructions



Center the heat shield around the hole and secure it to the wall with 6 - 1 ½" (38mm) screws in each of the holes.

You can place the Chimney "T" through the hole to help in centering the shield.



Place the stove in the correct position and center the floor plate under the stove.



Insert the "T" chimney piece through hole from the back of the sauna through the rear wall heat shield on the inside of sauna and into the chimney connector.



Remove the protective film from the chimney stacks.

Place the 2 chimney stacks together and secure with the included bracket.

Manufactured by:



TimberGlow

Wood Burning Sauna Heater

Installation Instructions



Attache assembled chimney pieces to the "T" coming out the back of the sauna and secure with the included bracket.



Remove the nuts and bolts from the chimney support.



Place the wall support piece, ensure the chimney is level and mark the position of the sides of the wall support bracket.



Secure the 2 wall brackets together with the provided nuts and bolts.

Manufactured by:



TimberGlow

Wood Burning Sauna Heater

Installation Instructions



Place the assembled bracket onto the marks and secure to the wall with the provided lag screws.



Attach the chimney to the bracket by placing the provided strap around the chimney and securing the strap to the bracket with the provided nuts, bolts, and washers.



Install the bottom half of the exterior chimney shield using 1 ½" (38mm) screws ensuring it is level.



Overlap the top half of the exterior chimney shield and secure with provided screws.

Manufactured by:



TimberGlow Wood Burning Sauna Heater Installation Instructions



Install the cap on the top of the assembled chimney.



Place the rocks in the heater until they are 2" (51 mm) above the top of the heater.

Congratulations! Your installation is now complete.



Manufactured by:
 **leisurecraft**
— BUILDING LUXURY —

tel: 888-923-9813 | info@leisurecraft.com | web: www.leisurecraft.com



WARRANTY

Dundalk LeisureCraft Inc. warrants our saunas against defects in materials and workmanship under normal/residential use for a period of five (5) years, as applicable, from the date of receipt of the product by the original end-user consumer. This warranty does not apply to normal wear and tear and/or natural weather conditions. This warranty does not cover regular required maintenance of the sauna, (eg. Tightening bands on the barrels, cleaning or staining the sauna) refer to your sauna assembly manual for maintenance guidelines. This warranty does not cover misuse or negligence, and the manufacturer and associated retailers are not liable for any injury or damage caused by the product. This warranty is a parts only warranty and any service or labor costs would not be considered as part of the 5-year warranty.

Purchaser Name: _____ Date: _____

Purchased From: _____

Manufactured by:



tel: 888-923-9813 | info@leisurecraft.com | web: www.leisurecraft.com